



LG G Pad F 8.0 Screen (LCD and Digitalizer) Replacement

Step by Step video of a replacement of the Digitalizer and LCD on a LG G Pad F 8.0.

Written By: Berry Patch IT Services

INTRODUCTION

Outline what you are going to teach someone how to do.

TOOLS:

- [iSesamo Opening Tool](#) (1)
- [Spudger](#) (1)
- [iFixit Opening Picks set of 6](#) (1)

PARTS:

- [LG G Pad F Screen](#) (1)
-

Step 1 — Insert Ilesmo opening tool between case and screen



- Work your way around tablet popping the clips loose

Step 2 — Disconnect Battery cable



- Carefully pry up on battery cable

Step 3 — Disconnect Charging port cable



- Not sure you have to remove this cable but better safe than sorry.

Step 4 — Remove screen from frame with Opening tool and picks.



- Carefully separate the Digitalizer screen from the frame be careful of the camera.

Step 5 — pry up the LCD and digitalizer from the case.

- Remove the screen from the top this will allow the display cable to pop loose from the back of the screen.

Step 6 — Remove all old tape or glue around edges.

- The cleaner you frame is the better the new screen sticks.

Step 7 — Apply new tape to frame.



- Use thicker tape on top and bottom and thinner tape on sides. Be careful not to cover camera and light sensor at the top.

Step 8 — Place screen in frame



- Insert screen into frame and slowly work around edges to seal new screen in place.

Step 9 — Place screen and frame back into case.



- Set the screen back into the case and snap back into place

To reassemble your device, follow these instructions in reverse order.