



# Dell XPS 13 L322X Base Plate Replacement

How to remove the base (bottom) to gain access to the components of the computer.

Written By: William Daniels



---

## INTRODUCTION

In order to get to the main source(s) of your computer, which is most likely inside of your computer, these are the necessary steps you can follow to remove the bottom cover.



### TOOLS:

- [T5 Torx Screwdriver](#) (1)
-

## Step 1 — Base Plate



**⚠ Shut down and unplug the device before beginning.**

- Use a Torx T5 screwdriver to remove the 10 screws from the computer's base plate.
- Use a prying tool or a fingernail to lift up and remove the base cover.

To reassemble your device, follow these instructions in reverse order.