



# Asus R541UA-RB51 Keyboard Replacement

This guide will walk through the steps for replacing the keyboard.

Written By: Drew Singleton



---

# INTRODUCTION



This guide is for replacing a broken of faulty keyboard.



## TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Keyboard



- Flip the laptop over so that the back panel is facing up.
- Carefully remove the eight 5.7mm screws on the back panel using a Phillips #1 screwdriver.


## Step 2



- Turn the laptop upright and flip the screen open.
- Using the plastic opening tool, gently pry the keyboard panel off of the base.



## Step 3



- Gently raise the keyboard from the base enough to access the underside.
- Gently pull up on the locking tab to release the ribbon cable. This should take no force to complete.
- Remove the keyboard.

To reassemble your device, follow these instructions in reverse order.