

Sony VAIO SVE14AJ16L Battery Replacement

This guide describes how to remove and replace the battery on a Sony VAIO SVE14AJ16L.

Written By: Allyson Karr



INTRODUCTION

This guide describes how to remove and replace the battery on a Sony VAIO SVE14AJ16L.



Step 1 — Battery



 Locate the lock and release switches on the battery.

Step 2





- Slide the lock switch open, then slide and hold the release switch on the battery.
- Then rotate the battery until it is facing straight up.

Step 3



 Finally, remove the battery pack from the computer.

To reassemble your device, follow these instructions in reverse order.