


Razer Phone Earpiece Speaker Replacement

How to replace the earpiece speaker on the Razer Phone.

Written By: Guneet Kohli



INTRODUCTION


Is your Razer Phone's speaker blown? If so, here is the guide to replacing it.



TOOLS:

- Phillips #000 Screwdriver (1)
- Jimmy (1)
- Tweezers (1)
- T5 Torx Screwdriver (1)
- Metal Spudger (1)

Step 1 — Display Assembly








- Remove the plastic speaker grills by using the metal spudger to pry underneath the strips.
- Peel off the plastic speaker grill to reveal the screws.
- (i) Heating up the plastic grills make them easier to remove.
- Peeling off the plastic speaker grill will ruin the adhesive used to keep it in place. A new adhesive must be used to put the grill back on the device.

Step 2





Pry the top plastic grill off with the metal spudger and reveal the screws.










- Remove five (two bottom, three top) 2.5 mm screws with the Phillips #000 screwdriver.
- Remove five (four bottom, one top) 5.5 mm screws with the Torx Head T5 screwdriver.


Step 4





- Remove the display assembly by using the Jimmy to separate the assembly from the phone's frame.
- Lift the display assembly away from the other half of the phone.









- Remove one 2.5 mm screw holding down the metal bracket connector using the Phillips #000 screwdriver.
- Peel back the metallic shielding over the connector using tweezers.
- Remove the metal bracket connector.

Step 6





 Grab hold of the the screen ribbon with the tweezers and remove it from the rest of the phone to free the assembly display.

Step 7 — Battery









- Grab hold of the connector on the right side of the phone (just above the battery) using the tweezers.
- Remove the connector.

Step 8






- Remove the 2.5 mm screw holding down the bracket with a Phillips #000 screwdriver.
- Grab the bracket with the tweezers and remove it.








Peel off and pull out the elastic tabs at the bottom of the battery.


Step 10







Carefully use the Jimmy to wedge the battery out of the phone.


Step 11 — Charging Port







- Using a Phillips #000 screwdriver, take out the seven 1 mm screws on the bottom panel of the device.
- (i) There are a few gold brackets under some of the screws. Make sure to remove these and keep them for reassembly.






- Grab hold of the blue connector on the upper left side of the phone with the tweezers.
- Remove the connector.






- Use the tweezers to grab hold of the connector for the blue wire (bottom of the device), and remove the connector.
- Use the tweezers to grab hold of the connector for the white wire, and remove the connector.


Step 14



 Using the tweezers, grab the detached charging port and ribbon.

Step 15 — Rear Camera





Remove the one 2.5 mm screw with the Phillips #000 screwdriver.


Step 16








• Remove the protective peel covering the rear cameras using your hands.



 Use the tweezers to remove the white tab connector.

Step 18



 Grab and remove the metal tab with the tweezers.










Grab the connectors with the tweezers and gently lift the connectors loose.

Step 20






Remove the one 2.5 mm screw with the Phillips #000 screwdriver.




 Remove the one 2.5 mm screw underneath the connectors with the Phillips #000 screwdriver.

Step 22








Grab the loose connectors with a tweezer and gently remove the rear camera unit from the phone.


Step 23 — Motherboard




 Grab and remove the blue connector with the tweezers.


Step 24






 Remove the five 1 mm screws holding down the gold antenna line brackets to the motherboard using the Phillips #000 screwdriver.







Remove the 2.5 mm screw next to the front-facing camera with the Phillips #000 screwdriver.

Step 26






Remove the four gold antenna line brackets with the tweezers.




 Using the tweezers remove the SIM card tray from the body of the phone.

Step 28



 Carefully lift up the motherboard away from the device.

Step 29 — Earpiece Speaker





Lift earpiece speaker up with the tweezers.

To reassemble your device, follow these instructions in reverse order.