

HP Pavilion 15-n232nr Battery Replacement

This guide will show how to remove the battery of an HP Pavilion 15-n232nr.

Written By: Elijah Gasmen



INTRODUCTION

This guide will show the steps in replacing the battery of the HP Pavilion 15-n232nr. The repairer will not need any tools to replace the battery. Prior repairing experience is not required.

Step 1 — Battery





Flip the laptop over.

Step 2







- Slide the battery locks towards the center of the laptop. The battery will detach automatically.
- Remove the battery by sliding it away from the laptop housing.

To reassemble your device, follow these instructions in reverse order.