



# Fairphone 3 Battery Replacement

This guide shows you how to remove and replace a worn-out or dead battery in your Fairphone 3.

Written By: Dominik Schnabelrauch



---

## INTRODUCTION

Use this guide to remove or to replace a worn-out or dead battery in your Fairphone 3.

If your battery is swollen, [take appropriate precautions](#).




### PARTS:

- [Fairphone 3 Battery](#) (1)
-

## Step 1 — Back Cover



-  Power off your phone before beginning disassembly.
- Insert a thumbnail, or a prying tool like a spudger, into the notch at the bottom right of the back cover.
  - Pry the back cover up to start separating its plastic clips.

## Step 2



- Slide around the bottom right corner of the back cover to loosen the lower plastic clips.
  - Lift the back cover to release the rest of the plastic clips and remove it.
- ☒ To reinstall the back cover press it firmly into place until you hear a snap from the plastic clips to form a seamless connection with the rear side of the phone.

## Step 3 — Battery



- Use a fingernail or a prying tool at the marked notch to lever the battery out of its recess.
- Lever the battery up until you can get a good grip.

## Step 4



- Lift the battery out of its recess and remove it.

For optimal performance, [calibrate your newly installed battery](#): Charge it to 100%, and keep charging it for at least two more hours. Then, use it until it shuts off due to low battery. Finally, charge it uninterrupted to 100%.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).