



# Vanmoof No 3 Replacement Mudguards

How to install new mudguards on an old No3 Vanmoof

Written By: Martin Hampton



## INTRODUCTION

Sounds easy, but you need to modify the new rear mudguard.

The most time consuming step is to buy the mudguards. This sounds easy except

- Vanmoof don't list the mudguards. Email Vanmoof support and they'll create a special sales link. You need to buy the M2/M3 mudguards which can be made to fit.
- They only ship to certain countries (why, it's just postage?). It took 6 months to pick mine up !!



## Step 1 — Get the Mudguards



- Make sure you get 2 mudguards, one set of stays that are straight for the rear, and a second that have a bend. Also make sure you have the two rear connection pieces.

## Step 2 — The problem



- You need to cut both sides of the mudguard so it can fit between the chain stays, and drill a new hole to attach to the bottom of the frame.

### Step 3 — Cut the rear mudguard



- The rear mudguard will need to be cut at the front.
- First cut at parallel to the bottom about 16mm long
- Second cut is 7mm in from the rounded edge

### Step 4 — Bend over the metal to make the edge



- Bend the edges over so you make a rounded lip

## Step 5 — Drill the new hole



- Drill the frame attachment hole

## Step 6 — Fit the rear mudguard



- Bolt to the frame

To reassemble your device, follow these instructions in reverse order.