

How to deregister VTech SN5107 Handset

Here's how to deregister your VTech SN5107 Handset if the screens is stucked with the message: "Out of range OR No power at base"

Written By: oklair



INTRODUCTION

Here's how to deregister your VTech SN5107 Handset if the screens is stuck with the message: "Out of range OR No power at base."

Step 1 — Introduction



 Here's how to deregister your VTech SN5107 Handset if the screens is stucked with the message: "Out of range OR No power at base"

Step 2 — Deregister the handset



- Press those keys on the handset:
- *331734#
- Then press the "Menu/Select" Button

Step 3 — Conclusion



 Your handset screen should now show "Registering... Please wait" or "To register HS, see manual", which means it is now ready to be registered to your SN5127 or SN5147 phone base.

Your handset screen should now show "Registering... Please wait" or "To register HS, see manual", which means it is now ready to be registered to your SN5127 or SN5147 phone base.