

MacBook Unibody Model A1342 Battery Replacement

Written By: Walter Galan



INTRODUCTION

This guide is an internal private guide used as a prereq.



F TOOLS:

• Spudger (1)

Step 1 — Battery



- For precautionary purposes, we advise that you disconnect the battery connector from the logic board to avoid any electrical discharge. This step is **optional** and is not required.
- Use the flat end of a spudger to lift the battery connector up out of its socket on the logic board.
- it may be easier to use your fingernails to lift up on both sides of the connector.

To reassemble your device, follow these instructions in reverse order.