
Ricoh YF-20 Super Lens Replacement

This process involves removing the back cover...

Written By: Eric Dazet



INTRODUCTION

This process involves removing the back cover and the front cover of the camera. After, the lens can be removed from the camera body.

TOOLS:

Phillips #1 Screwdriver (1)

Step 1 — Front Cover





- Unscrew the seven indicated screws from the left, right, bottom, and back sides of the camera.

Step 2








- Loosen the back cover from both the left and the right sides of the camera.


⚠ Remove back cover. The lid of the battery compartment may fall off because it is not attached to anything.



Step 3

- Open the film compartment.
  - Press your finger on top of the grey latch on the left side of the camera.

Step 4




ⓘ Removing the film compartment door is optional. However, it may aid maneuverability in future steps.




- Use a thin object like a toothpick or a small screwdriver to push down on the metal pin holding the film compartment door in place.
- Use your fingers to completely remove the metal pin.
- Remove the film compartment door.

Step 5




- Using a thin shaft screwdriver, unscrew the two indicated screws within the film compartment.

Step 6

- Loosen the front cover from the left and right sides of the camera.
- Remove the front cover.




Step 7 — Lens

⚠ The lens is only attached to the main camera body. Set the front and back covers aside.

- Unscrew three screws from the outermost plastic plate covering the lens.
- After the screws are removed, the outermost plate can be removed.

Step 8

- Remove the ring shaped metal brace.
- Using fingers or tweezers, remove the lens from the camera.

To reassemble your device, follow these instructions in reverse order.