



HP Compaq nc6400 Battery Replacement

This guide will take you through the process of...

Written By: Yoshitake Yamada



INTRODUCTION

This guide will take you through the process of replacing the battery in an HP Compaq nc6400 Laptop. You will need the correct replacement battery for your laptop to complete the installation.

Step 1 — Battery



⚠ Turn off and unplug laptop.

Step 2



- Locate the battery lock below the battery labeled one.
- Slide the lock all the way to the left to release the left lock of the battery.

Step 3



- Locate the lock labeled two at the bottom right corner below the battery.
- Slide and hold the lock to the left.

Step 4



- Once both the battery locks are unlocked, slide the battery out to remove.

To reassemble your device, follow these instructions in reverse order.