



PowerBook G4 Aluminum 12" 867 MHz Battery Replacement

Written By: iRobot



INTRODUCTION

Changing the battery is easy -- all you need is a coin.



TOOLS:

- [Coin](#) (1)



PARTS:

- [G4 Aluminum 12" Battery](#) (1)

Step 1 — Battery



- Use a coin to turn the battery locking screw 90 degrees to the right.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.