



2007 Chevy Aveo Indicator light bulb Replacement

Not a complicated job, but the trick is to pull the light assembly straight out. It does have some plastic studs that have a tendency of breaking off easy.

Written By: oldturkey03



INTRODUCTION

Here it is o'dark thirty and mother in law got pulled over by the local sheriff for a broken indicator. Nice Guy, let her off with a warning. She wants it changed NOW. The large tail light assemblies on the Aveo contains the brake and parking lights, turn signal and the back up lights.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Prying Tool](#) (1)

PARTS:

- [Sylvania Replacement Bulbs Item Number 12626463](#) (1)

Step 1 — Indicator light bulb



- Here is a view of the left tail light assembly
- Open the rear hatch,(or trunk if it is a sedan). On the inside of the assembly are two retaining screws. Remove those
- both screws are #6x3/4 inch

Step 2



- Here is a view of the assembly with the screws removed.
- Insert some sort of prying tool between the tail light assembly and the body, just below the crease in the body and pry to the rear of the vehicle. a snap will be felt/heard as the plastic stud releases
- Move the prying tool to above 1 1/2 inch above the bottom of the assembly. Insert it between the assembly and body and gently pry toward the rear of the vehicle. This should free the second stud.

Step 3



- Now just pull the assembly straight back.
- ⚠️ Avoid pulling the assembly to one side or another, that can snap the plastic studs
- Locate the burned out bulb. In this case it was the indicator light. Rotate the bulb sockets in a counterclockwise direction.
- Pull the sockets straight out of the tail light assembly.

To reassemble your device, follow these instructions in reverse order.