

Acer Aspire One P1VE6 Back Panel Replacement

This guide is a precursor to removing many of the internal components of the netbook including the fan, battery, hard drive, etc.

Written By: Wade Vierheller



INTRODUCTION

This will show you how to take off the back panel to get into the interior of the netbook.

TOOLS:

1

• Phillips #2 Screwdriver (1)

Step 1 — Back Panel



• Close the netbook and turn it over so the back panel faces you.

Step 2



• Locate the 4 mm Phillips #1 screw at the bottom of the back panel. Using the Phillips head screwdriver, remove the screw. Place the screw somewhere it will not be lost. Then remove the back panel by gently sliding it towards the front.

To reassemble your device, follow these instructions in reverse order.