

Dell Inspiron 15R Battery Replacement

This guide demonstrates how to remove the battery from this device.

Written By: Trixie Gonzalez



INTRODUCTION

Before performing any tasks on the device, be sure to remove the battery for safety reasons.

Step 1 — Battery



 Turn the device over and locate the battery.

Step 2





Place thumbs on each latch and push outwards.

Step 3



Push and slide the battery away from you.

To reassemble your device, follow these instructions in reverse order.