



Disassembling Sony Ericsson W200i Battery

Taking out the battery of the Sony Ericsson W200i.

Written By: Emily Prescott



INTRODUCTION

Removing the battery from the phone is simple, all you need is your fingers.

Step 1 — Disassembling Sony Ericsson W200i Battery



- Slide the battery cover up and off the phone.

Step 2



- Pop the battery out of its slot by lifting it up.

To reassemble your device, follow these instructions in reverse order. Make sure the indicated positive and negative signs match up with the phone upon replacement.