



iMac Intel 21.5" EMC 2389 Access Door Replacement

Replace the access door on your iMac Intel 21.5" EMC 2389.

Written By: Andrew Bookholt



INTRODUCTION

Use this guide to remove your access door.

TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Access Door



- Unplug your iMac's AC cord along with any peripheral devices.
- Lay your iMac face-down on a soft, clean surface as shown.
- ⚠ Be sure there isn't any dirt or debris on your work surface, as it may scratch the glass panel on the front of your iMac. We recommend placing a towel between the iMac and the work surface.
- Loosen the three Phillips screws securing the access door to the bottom edge of your iMac.
- ⓘ All three screws will remain captive in the access door.
- Remove the access door.

To reassemble your device, follow these instructions in reverse order.