



Macintosh PowerBook 165c Input/Output Door Replacement

This guide will demonstrate how to replace the Macintosh PowerBook 165c Input/Output door.

Written By: Jason



INTRODUCTION

Use this guide to replace or remove the Input/Output door.

Step 1 — Input/Output Door



- Orient the computer right side up with the rear facing you.
- Open the Input/Output (I/O) door.

Step 2



- Carefully bend the door into an arch until one of the pins releases from its slot.
- Once one of the pins is free, remove the I/O door from the computer.

To reassemble your device, follow these instructions in reverse order.