



Bose SoundLink Mini II 电池更换

警告：该设备具有硬连线电池主板连接。要更换电池，您需要获得技术手册和一个名为“Polycomm...”

撰写者: Devon



介绍

警告：该设备具有硬连线电池主板连接。要更换电池，您需要获得技术手册和一个名为“Polycomm”的专有软件。如果没有这个软件，请勿尝试更换电池。请查看第五步的图片以获取建议。

扬声器无法开机？本指南将帮助您更换Bose Soundlink Mini II的电池。

注意：拆卸和重新安装电池需要使用烙铁和非常小心的拆卸。还需要下载一种特定类型的专有软件“Polycomm”，并按照公司提供给 Bose 技术人员的维修指示进行操作。此类软件非常难以获取，获取其中的维修指南更是难上加难。

工具：

[TR9 Torx Security Screwdriver](#) (1)
[Mako Driver Kit - 64 Precision Bits](#) (1)
[Soldering Iron 60w Hakko 503F](#) (1)
[Desoldering Braid](#) (1)
[Lead-Free Solder](#) (1)
[Polycomm Software](#) (1)

章节：

[Bose SoundLink Mini II Battery](#) (1)

步骤 1 — 电池



- 将扬声器翻至底面向上。

步骤 2 — 拆下橡胶底座



- 通过拉动边缘，轻轻地从扬声器上取下橡胶底座。

步骤 3



- 卸掉电池角落的四颗6毫米T9 梅花型螺丝。

步骤 4



- 小心地从离四个金色接触针最近的一侧提起电池，但先不要试图完全拆卸它。
 - ❗ 此时，电池通过四根电线连接到电源板。
- 小心地从电源板上解售四根电线，以便完全拆卸电池。在不损坏外壳或板子的情况下，焊接铁的空间很小；你可能想先取下板子。
 - 有关焊接的帮助，请参阅[焊接指南](#)。
- ❗ 或者，您可以一起拆卸电池和电源板，无需任何焊接，但访问需要一些[额外的拆卸](#)，同时在整个过程中小心地通过电线保持电池连接。

步骤 5 — Bose 技术人员使用手册

entering the unit. Use a vacuum to remove any metal shavings. 1. Grille Removal Note: The grille is held in place by Pressure Sensitive Adhesive (PSA) strips located in the center of the grille (figure 5.) and also by two tabs on either end of the grille (figure 3). To avoid destroying the grill during the removal process, brush alcohol over the PSA strips (figure 5) before attempting to remove it. Important Note: To avoid damage to the cabinet, do not use the cabinet as a pry point to remove the grille. 1.1 At the location shown in Figure 3, insert the tip of a plastic tool, such as a spudger, between the grille and its rubber gasket. Note: The location shown is between the PSA and grille tabs securing the grille. 1.2 Rotate the spudger away from you while prying against the rubber gasket. Figure 4. 1.3 Once a portion of the grille is released, grasp the grille and pull it across the unit lengthwise to release the PSA. Figure 5. 2. Battery Removal The Battery in SoundLink® Mini II is hardwired to the Board PCB. See figure 6. Place the spudger	 Figure 3.  Figure 4.  Figure 5. 
--	--

- Bose 技术人员使用手册：
<https://riverparkinc.com/wp-content/uplo...>

要重新组装您的设备，请按相反的顺序按照以下说明操作。