



1992-1995 Honda Civic Oil and Oil Filter Replacement

A video tutorial on how to change the oil and oil filter on a 1992-1995 Honda Civic.

Written By: eCuration



INTRODUCTION

A video guide on how to change the oil and oil filter on a 1992-2000 Honda Civic.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Oil Drain Pan](#) (1)
- [Oil Filter Wrench](#) (1)
- [Long Neck Funnel](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [17 mm Box End Wrench](#) (1)
- [Paper Towels](#) (1)
- [Torque Wrench](#) (1)
- [Socket 17mm](#) (1)



PARTS:

- [5W-30 Motor Oil](#) (4)
- [Oil Filter Honda Civic 1992-2000](#) (1)

To reassemble your device, follow these instructions in reverse order.