



# Sharp LC-37SB24U Television CCFL Replacement

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Written By: Steve Baker



---

## INTRODUCTION

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Always disconnect the power several minutes prior to working on a television to avoid risk of shock. Also use caution with CCFLs, they contain mercury.

This unit shuts off the screen after 2 seconds when a lamp failure is detected.

---

### TOOLS:

- [Mahi Driver Kit - 48 Bit Driver Kit](#) (1)
  - [Metal Spudger](#) (1)
-

To reassemble your device, follow these instructions in reverse order.