



Samsung HMX-F90 Battery Replacement

Remove the battery of an HMX-F90 Camcorder for battery replacement or case removal.

Written By: Amir Harb



INTRODUCTION

Batteries can lose their ability to retain charge over time. This guide can be used to remove the battery of an HMX-F90 Camcorder for battery replacement or allow for deeper repairs requiring case removal.

Step 1 — Battery



- Pull the release tab away from the battery.
- Slide the battery towards the release tab and then pull the battery away from the camcorder.

To reassemble your device, follow these instructions in reverse order.