

Samsung HMX-F90 Strap Replacement

Removing and replacing the strap of the HMX-F90 Camcorder.

Written By: Amir Harb



INTRODUCTION

Overtime velcro on the strap will become worn out which can cause the HMX-F90 to become difficult to hold. This guide can be used to replace the worn out hand strap.



TOOLS:

Phillips #00 Screwdriver (1)

Step 1 — Battery







- Pull the release tab away from the battery.
- Slide the battery towards the release tab and then pull the battery away from the camcorder.

Step 2 — Strap Side Outer Casing





- Rotate the camcorder so that the strap side is facing you.
- Locate and remove the three 4.5mm Phillips #00 screws around the hand strap.

Step 3





- Rotate the camcorder so that the battery slot is facing you.
- Located in the top left corner of the battery slot, remove the 4.5mm Phillips #00 screw.

Step 4





- Rotate the camcorder so you are looking at the bottom of the camcorder.
- Locate and remove the last three 4.5mm Phillips #00 screws.

Step 5







With both hands, pull the side strap apart from the rest of the camcorder.

Step 6 — Hand Strap







- Unfasten the strap from the outside.
- Pull apart the velcro on the faux leather strap sheath to reveal the separate end of the strap.
- The loose end can be pulled off the velcro and fed through the loop on the casing to free one end of the strap.

Step 7







- On the inside of the opened case, locate the silver metal plate and remove the 3mm Phillips screw.
- Feed the strap through the hole to remove completely so that it can be replaced or cleaned.

To reassemble your device, follow these instructions in reverse order.