Dell Vostro 14 3468 Memory Module Replacement

Written By: Johnathan Hammond


This document was generated on 2021-03-12 12:27:31 PM (MST).

🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- Spudger (1)

Step 1 — Battery

- Slide the release latch to unlock the battery [1].
  - Remove the battery from the computer [2].

Step 2 — Optical-Disk Drive

- Remove the screw that secures the optical drive to the computer [1].
  - Using a plastic scribe, push the tab to release the optical drive [2].
    - Slide the optical drive out of the computer [3].

This document was generated on 2021-03-12 12:27:31 PM (MST).

Step 3 — KeyBoard

- Release the keyboard by prying on the keyboard release tabs using a plastic scribe [1].

- Slide and lift the keyboard to access the keyboard connector cable under the keyboard [2].

Step 4

- Disconnect the keyboard cable from the system board.
  - Lift the keyboard cable to remove it from the computer.

This document was generated on 2021-03-12 12:27:31 PM (MST).

Step 5 — Base Cover

- Disconnect the optical drive connector and lift it to remove it from the system board [1].

 - Remove the screws inside the palmrest [2].

Step 6

- Remove the screws that secure the base cover to the computer

This document was generated on 2021-03-12 12:27:31 PM (MST).

Step 7

- Pry the edges of the base cover [1].
  - Lift the base cover and remove it from the computer [2].

Step 8 — Memory Module

- Pull the clips securing the memory module until the memory module pops up [1].
  - Remove the memory module from the system board [2].

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2021-03-12 12:27:31 PM (MST).