Asus G73JH-RBBX05 Keyboard Replacement

Replace the keyboard on the Asus G73JH-RBBX05

Written By: Josh DeBest

This document was generated on 2020-11-28 05:52:01 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 3

INTRODUCTION

Use this guide to remove the keyboard on the Asus G73JH-RBBX05.

TOOLS:

- Metal Spudger (1)
- Spudger (1)

PARTS:

- ASUS ROG G73Jh Keyboard (1)

This document was generated on 2020-11-28 05:52:01 AM (MST).

Step 1 — Keyboard

- Locate the 5 clips located at the top of the keyboard. Insert a metal spudger into the clip openings on the keyboard to remove the keyboard.

Step 2

- Before fully removing the keyboard, remove the back lighting cable and keyboard data strip.

- In order to remove these cables, push forward the black retention clips and pull out the cables.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 05:52:01 AM (MST).