

Alienware Aurora A5 SSD Replacement

This guide shows how to replace a NVMe M2 SSD...

Written By: Sarah Mohammed



INTRODUCTION

This guide shows how to replace a NVMe M2 SSD card. Replacing a M2 SSD is necessary when the part is defective or when you need to upgrade the storage capacity as it's the main component for storing vital data for the PC.

Before beginning, make sure to turn off the PC and unplug the power cable.

✓ TOOLS:

PARTS:

Phillips #1 Screwdriver (1)

Crucial P5 3D NAND PCle M.2 SSD (1)

Step 1 — SSD





Power off the computer.

⚠ To ensure the PC is completely off, remove the cables at the back of the PC.

Step 2




- Lift the black latch at the back of the PC to pop open the side cover.
- Carefully remove the side cover by lifting it up.

Step 3




- Unlock both tabs on the back of the PC by pushing them up.
- Remove the power supply latch to get access to the inside.

Step 4







- Remove the black plastic part by pushing it down and then pulling it towards you.
- Unlock the blue latch and pull to remove the graphics card.

Step 5







Use the Phillips #1 screwdriver to remove the 3.7 mm screw and remove the old M2 SSD.

Ensure that you tightly screwed on the M2 SSD and that you inserted the graphics card back to its position so that the PC runs smoothly with no problems. Once you have completed all the steps and reconnected the cables you have successfully replaced the NVMe M2 SSD and your PC is ready to be turned on!