



LERSTA Floor Lamp Screw Terminal Replacement

This guide is about replacing screw terminal of floor lamp if the socket is bad after testing the socket for power with a circuit tester that lights off.

Written By: Jiajun Guo



INTRODUCTION

This guide is about substituting the screw terminal of floor lamp, providing that the lamp socket is bad when normally trying to test the socket for power with a \$5 circuit tester that lights off.

If you notice your lamp's cords and plug are intact, or your lamp's lighting bulb is properly functioning, then your lamp's lighting socket may need to be replaced.

TOOLS:

- Craftsman 5 16" x 1 3 4" slotted screwdriver
phillips screwdriver (1)

PARTS:

- E27 Lighting Accessory Plastic Light Bulb
Socket (1)

Lighting accessory

*This light bulb socket is specified as lamp
base in lighting accessory.*

Step 1 — Screw Terminal



- Unplug the lamp.

Step 2



- Rotate the bulb counterclockwise to remove the light bulb.

Step 3



- Rotate the lamp shade counterclockwise.

Step 4



- Take the three parts aside after dismantling the lamp shade.

Step 5



- Dismantle the lamp shaft by rotating it counterclockwise.

Step 6




- Use a Phillips screwdriver to remove the two 3 mm screws from the silver cover.
- Pull down both the silver cover and the black screw terminal.

Step 7



- Separate the light bulb socket from the silver cover by pulling the silver metal hasp in right-downward direction towards the lamp shaft.
- ⓘ Exert force on the both left and right hand sides of the hasp and then pull the hasp downward.

Step 8



- Replace the old bulb socket with a newly-purchased one.

To reassemble your device, follow these instructions in reverse order.

Replacing the screw terminal of the floor lamp is relatively easy, but be cautious to deal with the step of the substitution of the light socket.